

Property of INPUT/OUTPUT, INC.

**TABLE OF CONTENTS**  
**SYSTEM CONTROL MODULE/SYSTEM INTERFACE MODULE/TAPE**  
**TRANSPORT MODULE**

**VOLUME II**

<b>134300</b>	.....	<b>SIM Assembly</b>
<b>134300</b>	.....	<b>Parts List, SIM Assembly</b>
<b>134060</b>	.....	<b>W/W Assembly, Motherboard, SCM</b>
<b>134060</b>	.....	<b>Parts List, Motherboard, SCM</b>
<b>134062</b>	.....	<b>Schematic, Motherboard, SCM</b>
<b>134305</b>	.....	<b>W/W Assembly, Interconnect Log, SIM</b>
<b>134305</b>	.....	<b>Parts List, Interconnect Log, SIM</b>
<b>134307</b>	.....	<b>Schematic, Interconnect Log, SIM</b>
<b>134325</b>	.....	<b>PC Assembly, Intercom, SIM</b>
<b>134325</b>	.....	<b>Parts List, Intercom, SIM</b>
<b>134327</b>	.....	<b>Schematic, Intercom, SIM</b>
<b>134210</b>	.....	<b>PC Assembly, XI-STC2922, TTM</b>
<b>134210</b>	.....	<b>Parts List, XI-STC2922, TTM</b>
<b>134212</b>	.....	<b>Schematic, Transport Interface</b>
<b>134108</b>	.....	<b>Case Assembly, SCM, IOSO</b>
<b>134108</b>	.....	<b>Parts List, Case Assy., SCM, IOSO</b>
<b>133290</b>	.....	<b>PC Assembly, Power Monitor</b>
<b>133290</b>	.....	<b>Parts List, Power Monitor</b>
<b>133292</b>	.....	<b>Schematic, Power Monitor</b>
<b>133298</b>	.....	<b>Cable Assembly, PCB to Case, PM1</b>
<b>133298</b>	.....	<b>Parts List, PCB to Case, PM1</b>
<b>133305</b>	.....	<b>PC Assembly, Power Distribution, PM1</b>
<b>133305</b>	.....	<b>Parts List, Power Distribution, PM1</b>
<b>133307</b>	.....	<b>Wiring Diagram, Power Monitor System</b>
<b>134085</b>	.....	<b>PC Assembly, Enhanced Playback Filter, 4P</b>
<b>1340850003</b>	.....	<b>Parts List, Enhanced Playback Filter, 4P</b>
<b>134087</b>	.....	<b>Schematic, ENH Playback Filter</b>
<b>134445</b>	.....	<b>PC Assembly, Tape Controller SCSI</b>
<b>134445</b>	.....	<b>Parts List, Tape Controller SCSI</b>
<b>134447</b>	.....	<b>Schematic, Tape Controller SCSI</b>
<b>134470</b>	.....	<b>PC Assembly, Plotter Interface, SCM</b>
<b>1344700001</b>	.....	<b>Parts List, Plotter Interface, SCM</b>
<b>134472</b>	.....	<b>Schematic, Plotter Interface, PC, SCM</b>
<b>131201</b>	.....	<b>Cable Assembly, OCM Scribe Master</b>
<b>131201</b>	.....	<b>Parts List, OCM Scribe Master</b>
<b>134031</b>	.....	<b>Wiring Diagram, Power Distribution</b>