

Property of INPUT/OUTPUT, INC.

**I/O SYSTEM TWO
RSR CABLES MANUAL
TABLE OF CONTENTS**

131019	CABLE ASSEMBLY, POWER INV., I/O SYSTEM ONE
1310190006	PARTS LIST, POWER INV., I/O SYSTEM ONE
134887	CABLE ASSEMBLY, 12V POWER, CTR EXT
1348870010	PARTS LIST, 12V POWER, CTR EXT
134892	CABLE ASSEMBLY, ENC-301 TO OCR
1348920006	PARTS LIST, ENC-301 TO OCR
134893	CABLE ASSEMBLY, CNTRLEXT, CTR
1348930010	PARTS LIST, ECTRLEXT, CTR
134894	CABLE ASSEMBLY, RSR TEST STN/DATA COLLECTOR
1348940001	PARTS LIST, RSR TEST STN/DATA COLLECTOR
134895	CABLE ASSEMBLY, RSR TEST STN/HHT
1348950001	PARTS LIST, RSR TEST STN/HHT
134897	CABLE ASSEMBLY, ANTENNA MAST
1348970001	PARTS LIST, ANTENNA MAST
134898	CABLE ASSEMBLY, DCU TO TTM-45
1348980003	PARTS LIST, DCU TO TTM-45
134899	CABLE ASSEMBLY, SCSI-ND TO TTM-45
1348990006	PARTS LIST, SCSI-ND TO TTM-45
135152	CABLE ASSEMBLY, ENC-301 TO OCR/SSI
1351520001	PARTS LIST, ENC-301 TO OCR/SSI
135153	CABLE ASSEMBLY, POWER METER TO CTR
1351530006	PARTS LIST, POWER METER TO CTR
135158	CABLE ASSEMBLY, ROTATOR, ANT., RSR
1351580001	PARTS LIST, ROTATOR, ANT., RSR
135182	CABLE ASSEMBLY, DCU TO RSR3
1351820006	PARTS LIST, DCU TO RSR3
135183	CABLE ASSEMBLY, DCU TO RSR W/DVI
1351830006	PARTS LIST, DCU TO RSR W/DVI
135184	CABLE ASSEMBLY, DCU TO RSR-3 W/DVI
1351840006	PARTS LIST, DCU TO RSR-3 W/DVI
135185	CABLE ASSEMBLY, B. CHARGER, 6 PIN, RSR BUOY
135187	CABLE ASSEMBLY, B. CHARGER, 16 PIN, RSR BUOY
1351870001	PARTS LIST, B. CHARGER, 16 PIN, RSR BUOY
139760	CABLE ASSEMBLY, DCU TO RSR
1397600006	PARTS LIST, DCU TO RSR